


**Product: S-Line Single**  
montage handleiding



**Technische data**


Kolom trap	3
Max. gewicht capaciteit	125KG
Hoogte bereik	650-1300mm
Breedte bereik	1100-1900mm

**Accessoire lijst**

No.	beeld	specs	aantal
A		M6	4
B		M6	4
C		M6	8
D		M6	8
E		5/4_2	16
F		Inbus 4x4mm	1



**Componenten lijst**

Nr.	Part	Qty	Nr.	Part	Qty
1	Teen	2	2	Verstel kolom	2
Nr.	Part	Qty	Nr.	Part	Qty
3	Magnetische kabelhouder	1	4	Telescopische beam control box indicator	1
Nr.	Part	Qty	Nr.	Part	Qty
5	Bladdrager	2	6	Memory unit	1
Nr.	Part	Qty			
7	Stroomkabel	1			



**STAP 1**


Monteer de bladdragers



Bevestig de bladdragers(5) op de einden van de telescopische beam (4) met de boutjes(A) en met de inbusleutel(F).

**STAP 2**



Monteer de verstel kolommen



Plaats de kolommen(2) op de aangegeven plaats in de beam(4). Zet de kolommen vast met de boutjes(D) met de inbusleutel(F).

**STAP 3**

Monteer de tenen






Plaats de tenen(1) op de verstel kolommen(2). Zet de tenen vast met de boutjes(C) met de inbusleutel(F).

## STAP 4


Bevestig het werkblad

1





de breedte van het frame kan worden ingesteld op de bladmaat

2




3



## STAP 6

Monteer de magnetische kabelhouder



Zorg dat de magnetische kabelhouder (3) aan beiden zijden goed blijft vastzitten aan de metalen beams

### Voorkomende foutmeldingen

De volgende tips kunnen helpen bij de veelvoorkomende foutmeldingen en errors. Mocht de foutmelding niet in deze lijst voorkomen of uw probleem blijft bestaan, neem dan svp contact op met uw leverancier.

Foutmelding	oplossing
Geen reactie nadat u de knop naar beneden lang heeft ingedrukt	1. Controleer of u de knop juist op aansloot 2. Neem contact op met uw leverancier
no response while pressing up arrow down arrow after connected with a power supply	1. Controleer of u de knop juist op aansloot 2. Neem contact op met uw leverancier
le in gebruik onthoog	1. controleer gewicht. Max. gewicht: 125kg 2. Neem contact op met uw leverancier
motorren doen niets	1. Neem contact op met uw leverancier
frame gaat alleen naar beneden en niet onthoog	1. Het gewicht 2. Neem contact op met uw leverancier
Frame zakt naar beneden	1. controleer gewicht. Max. gewicht: 125kg 2. Neem contact op met uw leverancier
Frequent repositioneren	1. controleer gewicht. Max. gewicht: 125kg 2. Neem contact op met uw leverancier
Overstaptoestel (max. gewicht: 200 kg inclusief 20 liter water)	1. controleer gewicht. Max. gewicht: 125kg 2. Neem contact op met uw leverancier
onvoldoende hoogte/laagte bereik	1. Druk het knop 15 seconden omhoog of langer. Niet het knop 2 seconden naar beneden. Het knop 20 seconden. 2. Neem contact op met uw leverancier




### Attention

- Power supply: AC100V-240V,50/60Hz
- Service Environment: 0-40°C
- Unplug the power plug before cleaning. Wipe the dust on surface with slight wet dishcloth when cleaning, be careful not to let the drops into the internal parts, not loose the connector.
- The electric box contains electronic components, metals, plastics, wires etc., so dispose of it in accordance with each country's environmental legislation, not the general household waste.
- Check carefully to ensure correct and complete assembly before using.
- Be familiar with all functions and program settings of the product before first use.
- Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on manufacturers.
- Slight noise caused by the V ribbed belt or brake system due to structure will not have any effect on the use of the equipment.
- Caustic or abrasive materials are forbidden to clean the equipment. Must ensure that the cleaner used will not pollute the environment.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- Please make sure there is no hazard sources in your operating environment, e.g., do not avoid any possible danger, e.g., plastic bag may lead to choking hazard to children.
- Keep the original package of the equipment if necessary in case of the future use in transportation.


## STAP 5

Installeer de control box



Poort voor Memory unit

Poort voor aansluiten kabels van de verstel kolommen



### Waste disposal



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Swan Products  
Business Park "Hot Hoog"  
Mandenmaker 15  
5253 RB Nieuwkuijk  
Tel: +31(0)73-63 12 675