

Headrest adjustment:

To adjust the headrest height, lift up the headrest (①) to desired position.
To adjust the headrest angle, turn the headrest directly to desired angle.

Armrest adjustment (②):


To rise up or lower down the armrest, hold up the armrest little bit and turn the adjustment wheel under the armrest to desired position.

Backrest independent angle adjustment:

To change the backrest angle, when sit on the chair, hold the handle (③) and lie back to desired position, then release the handle to lock.

Seat height adjustment:

To raise the seat height, remove weight from the seat and pull up on the height adjustment lever (④), release the lever when reaching the desired position.
To lower the seat height, while seated, pull up slowly on the height adjustment lever until the seat is at the desired height.



Tilt angle adjustment:

To change backrest tilt angle, pull up the adjustment lever (⑤), then lie backwards the backrest to desired position, and push down the adjustment lever to lock.
To go back to the first position, pull up the adjustment lever, lie backwards again and then backrest will return automatically.

Tilt tension adjustment:

To adjust the seat tilt tension, turn the tension adjustment knob (⑥) on the mechanism to desired tension, turn clockwise or anticlockwise.
Clockwise to make it hard.
Anticlockwise to make it easy.

Lumbar support adjustment:

To enlarge the lumbar support (air bag) depth, hold and press the pump (⑦) until it reach your desired position.
To reduce the depth, press the button (⑧) on the pump to release the air until it reach your desired position.

